

# Warranty

Xtracycle U-Tube LT2 Retrofit Kit is guaranteed to be free from manufacturing defects for one (1) year from the original date of purchase.

Defective products will be repaired or replaced at Xtracycle's discretion. To determine if a warranty claim is valid you may be required to return the product to Xtracycle for inspection. Xtracycle is not responsible for removal, installation or shipping costs. This warranty applies only to the original buyer and is not transferable.

This warranty does not cover damage from use of this product outside of its intended range or that resulting from modification or neglect. It also does not cover wear and tear resulting from the normal use of the product.

<http://www.xtracycle.com/register>

**Our mission:**  
To empower people with  
transformational tools that  
move the body and spirit.



# XTRACYCLE

## U-Tube Retrofit Kit

The Key Piece to Convert LT2 U-Tubes  
to fit on your LT1 Xtracycle



### What's Included:

4 Anchors

**Note:** This guide is meant to be used in combination with LT2 U-Tube manuals.

### Tools Needed:

- Mallet
- 3mm Allen Wrench

[www.xtracycle.com](http://www.xtracycle.com)

## STEP 1:

### *Insert U-Tubes*



**Step 1:** Insert a U-Tube into the horizontal ports. Like Hooptie, U-Tubes have a narrow setting, and a wide setting. Wide setting will work well for passengering with loaded cargo bags. The narrow setting will work better if bags are not loaded.

## STEP 2:

### *Insert Anchors*



**Step 2:** Insert anchor into lined up hole. Using a mallet, push anchor until it is flush with Xtracycle frame.

## STEP 3:

### *Flush Anchor with Xtracycle Frame*



## STEP 4:

### *Thread M5 Bolt*



**Step 4:** Thread M5 bolt and lock washer into the anchor. Do not over tighten.

Repeat steps 1-4 on the opposite side of the u-tube, and then repeat for the second U-Tube.

**Note:** These can not be re-used after installation. You will need a new kit if you remove the U-tubes and need to reinstall them.