

SuperHooks Installation Manual

Included

- (4) SuperHooks
- (4) M6 x 30mm counter sunk bolts

Tools needed

6mm Allen key



Note: SuperHooks are required to securely install a LT1 version 2 FlightDeck onto a set of LT1 V-racks. If you intend to install a Yepp Maxi seat on your LT1 version 2 FlightDeck, you will need two sets of SuperHooks for a total of 8 hooks.

Installing SuperHooks

1. Apply grease to threads of all four M6x30mm bolts
2. Insert bolts into the counter-sunk holes at each corner of your LT1 V2 deck
3. Thread SuperHooks onto the four bolts but do not tighten
4. Place deck onto V-Racks and rotate hooks to engage V-Rack rails
5. Ensuring the hooks are contoured to the V-Rack rails, tighten bolts
6. If installing Yepp seats, an extra set of SuperHooks are required
7. Install second set of SuperHooks into the four inner counter-sunk holes